

# TAYA 8119

All-leather gloves made of cowhide. Gloves combine high heat resistance with a back reinforcement of para-aramid.

## PRODUCT DESCRIPTION

Colour:  Black  
TAYA Compact 8119-06

### UPPER MATERIAL:

- Grain cowhide leather – specially treated, heat, water and abrasion resistant.

### REINFORCEMENT:

- Back: Para-Aramid reinforcement with silicone coating and shock-absorbing filling.
- Palm: Leather reinforcement.

### INTERMEDIATE LAYER:

- Aramid non-woven fabric.

### MEMBRANE:

- FR Porelle®.

### LINING:

- Aramid lining.

### CUFF:

- Compact – Grain cowhide leather with Velcro drawstring.

### OTHER INFORMATION:

- Gloves with anatomical cut.
- Reflective element.
- Carabiner for hanging the gloves on clothing.

### STANDARDS:

- EN 659:2003+A1:2008



TAYA Compact

# TAYA 8119

Measurement:	Results before washing:
Abrasion resistance	4
Blade cut resistance (palm part)	3 / TDM Level C
Tear resistance	4
Puncture resistance	4
Burning behaviour	4
Convection heat resistance	4
Radiant heat resistance	2
Contact heat resistance	2
Dexterity	5

## SIZE ASSORTMENT:

 cm	15,2-16,5	16,5 - 19	19 - 21,6	21,6 - 24,2	24,2 - 26,7	26,7 - 29,2	29,2 - 30,4
size	6 (XS)	7 (S)	8 (M)	9 (L)	10 (XL)	11 (2XL)	12 (3XL)

## CARE & MAINTENANCE:

Choose a more ecological short washing program at 40 °C.



**PROCEDURE:** Remove coarse dirt after each use. Before washing, fasten the Velcro fasteners and remove the snaps. Use a liquid detergent. Wash on a short programme.

**TO MAKE THE GLOVE FIT BETTER:** Shape the glove several times after washing and during drying. Do not dry in direct sunlight or heat sources, do not use a tumble dryer. Store the gloves in a dry environment.

## RECOMMENDED USE:

### Holík Washing Gel

The washing gel is natural based for leather and textile gloves with high washing efficiency. It reduces bacteria, does not pollute the environment and is fully biodegradable (Eco-Friendly).



### Impregnation spray Holík

A highly effective impregnating spray for leather and textiles that protects against moisture, water, oil and dirt while maintaining the breathability of the material. Apply the impregnation in a thin layer on dry product and allow to dry for at least 12 hours.

For more about Washing & Maintenance, visit:  
[www.holik-international.com](http://www.holik-international.com) > [Technologies](#) > [Care&Maintenance](#)



Co-funded by  
the European Union

