

BRELA 8115

Basic model of our collection of all-textile gloves is characterized by high sensitivity and flexibility.



BRELA Flexi



BRELA Easy Beige



BRELA Short











BRELA Long



BRELA Flexi Beige

PRODUCT DESCRIPTION

BRELA Flexi		Navy Blue	8115-01
BRELA Easy		Navy Blue	8115-03
BRELA Long		Navy Blue	8115-04
BRELA Short		Navy Blue	8115-05
BRELA Flexi		Beige	8115-11
BRELA Easy		Beige	8115-13
BRELA Long		Beige	8115-14
BRELA Short		Beige	8115-15

UPPER MATERIAL:

- **Back:** Kermel® fabric with hydrophobic and oleophobic treatment.
- **Palm:** Meta-aramid / Para-aramid knit with silicone coating.

INTERMEDIATE LAYERS:

- Insulation layer – Recycled aramid non-woven fabric.
- Membrane – PU membrane.

CUFF:

- **Flexi** – Cuff made of flame retardant knitted fabric with stable internal elasticity.
- **Easy** – Cuff made of Kermel® fabric.
- **Long** – An extended cuff that protects the user's forearm.
- **Short** – Basic cuff made of Para-Aramid knitting.
-

LINING:

- Aramid lining.

STANDARDS:

- EN 659:2003+A1:2008.

EN 659




BRELA 8115

OTHER INFORMATION:

- Anatomical cut glove.
- Reflective elements.
- Carabiner for hanging the gloves to the garment.

Measurement type:	Results before washing:
Abrasion resistance	4
Blade cut resistance (palm part)	5
Tear resistance	4
Puncture resistance	3
Burning behaviour	4
Convection heat resistance	4
Radiant heat resistance	2
Contact heat resistance	2
Dexterity	5

SIZE ASSORTMENT:

cm 	12,7-15,2	15,2-16,5	16,5 - 19	19 - 21,6	21,6 - 24,2	24,2 - 26,7	26,7 - 29,2	29,2 - 30,4	30,4-32,9
size	5 (XXS)	6 (XS)	7 (S)	8 (M)	9 (L)	10 (XL)	11 (2XL)	12 (3XL)	13 (4XL)

CARE & MAINTENANCE:

Choose a more ecological short washing program at 40 °C. Wash at a maximum temperature of 60 °C if you need to disinfect the gloves or they are extremely dirty.



PROCEDURE: Remove coarse dirt after each use. Before washing, fasten the Velcro fasteners and remove the snaps. Use a liquid detergent. Wash on a short programme. **TO MAKE THE GLOVE FIT BETTER:** Shape the glove several times after washing and during drying. Do not dry in direct sunlight or heat sources, do not use a tumble dryer. Store the gloves in a dry environment.

RECOMMENDED USE:

Holík Washing Gel

The washing gel is natural based for leather and textile gloves with high washing efficiency. It reduces bacteria, does not pollute the environment and is fully biodegradable (Eco-Friendly).



Impregnation spray Holík

A highly effective impregnating spray for leather and textiles that protects against moisture, water, oil and dirt while maintaining the breathability of the material. Apply the impregnation in a thin layer on dry product and allow to dry for at least 12 hours.

For more about Washing & Maintenance, visit:
www.holik-international.com > Technologies > Care&Maintenance



Co-funded by
the European Union

