

BRYN 8117

Combination intervention gloves with PTFE membrane and D3O[®] back protection. High sensitivity is ensured by an innovative design of the intermediate fingers and seamless fingertips.



BRYN Compact



BRYN Short



BRYN Long

PRODUCT DESCRIPTION

Colour:	■ Grey
BRYN Long	8117-04
BRYN Short	8117-05
BRYN Compact	8117-06

UPPER MATERIAL:

- **Back:** Heat, water and abrasion - resistant calf split leather.
- **Palm:** Meta-aramid / Para-aramid knit with silicone coating.

REINFORCEMENT:

- **Back:** Reinforcement made of aramid material with silicone coating and filling made of D3O[®] material.

INTERMEDIATE LAYERS:

1. Isolation layer – Aramid non-woven fabric.
2. Membrane – PTFE Porelle[®].

LINING:

- Aramid lining.

CUFFS:

- **Compact** – Cuff with Velcro tightening strap.
- **Long** – Extended cuff made of cowhide split and with Velcro drawstring.
- **Short** – Para-aramid knitted cuff.

OTHER INFORMATION:

- Anatomical cut glove.
- Innovative material cut design in the mid-finger (split-Nomex[®]).
- No seams at fingertips.
- Reflective element.
- Carabiner for hanging the gloves to the garment.
- Drawstring waistband with velcro closure.

STANDARDS:

- EN 659:2003+A1:2008



BRYN 8117

Measurement:	Before washing:
Abrasion resistance	4
Blade cut resistance (palm part)	5
Tear resistance	4
Puncture resistance	3
Burning behaviour	4
Convection heat resistance	4
Radiant heat resistance	2
Contact heat resistance	2
Dexterity (short cuff)	2
Dexterity (compact cuff)	2
Dexterity (long cuff)	Level 3

SIZE ASSORTMENT:

cm	15,2-16,5	16,5 - 19	19 - 21,6	21,6 - 24,2	24,2 - 26,7	26,7 - 29,2	29,2 - 30,4
size	6 (XS)	7 (S)	8 (M)	9 (L)	10 (XL)	11 (2XL)	12 (3XL)

CARE & MAINTENANCE:

Choose a more ecological short washing program at 40 °C. Wash at a maximum temperature of 60 °C if you need to disinfect the gloves or they are extremely dirty.



PROCEDURE: Remove coarse dirt after each use. Before washing, fasten the Velcro fasteners and remove the snaps. Use a liquid detergent. Wash on a short programme.

TO MAKE THE GLOVE FIT BETTER: Shape the glove several times after washing and during drying. Do not dry in direct sunlight or heat sources, do not use a tumble dryer. Store the gloves in a dry environment.

RECOMMENDED USE:

Holík Washing Gel

The washing gel is natural based for leather and textile gloves with high washing efficiency. It reduces bacteria, does not pollute the environment and is fully biodegradable (Eco-Friendly).



Impregnation spray Holík

A highly effective impregnating spray for leather and textiles that protects against moisture, water, oil and dirt while maintaining the breathability of the material. Apply the impregnation in a thin layer on dry product and allow to dry for at least 12 hours.

For more about Washing & Maintenance, visit:
www.holik-international.com > Technologies > Care&Maintenance



Co-funded by
the European Union

