

BRYN

Combination intervention gloves with PTFE membrane and D3O® back protection. High sensitivity is ensured by an innovative design of the intermediate fingers and seamless fingertips.



Bryn Compact

Bryn Compact 8117-03

Gray

Bryn Long 8117-06

Gray

Bryn Short 8117-04

Gray

UPPER MATERIAL:

- Back: Heat, water and abrasion - resistant calf split leather.
- Palm: Meta-aramid / Para-aramid knit with silicone coating.

REINFORCEMENT:

- Back: Reinforcement made of aramid material with silicone coating and filling made of D3O® material.

INTERMEDIATE LAYER:

- Aramid nonwoven fabric.

MEMBRANE:

- Porelle® PTFE membrane.

LINING:

- Aramid lining.

CUFFS:

- Compact - Calf split leather.
- Long - Calf split leather.
- Short - Kevlar® knitted wristband.




Bryn Long

Bryn Short



BRYN

 (cm)	16,7–19,2	19,2–21,7	21,7–24,2	24,2–26,7	26,7–29,2	29,2–31,7
size	7 (S)	8 (M)	9 (L)	10 (XL)	11 (XXL)	12 (3XL)

OTHER INFORMATIONS:

Anatomical cut of the glove.

Innovative construction of material cut in the middle finger (split-Nomex®).

Absence of seams on fingertips.

Reflective element.

Carabiner for hanging gloves to clothing.

Cable tie with velcro fastening.

CARE AND STORAGE

Remove excess dirt after every use.

Before washing fasten the velcro and remove the carabiners.

Use liquid detergent.

Wash gloves at the short program.

To make the glove fit better: After washing and during drying shape the glove several times.

Do not dry in direct sunlight, or on heat sources, do not use the dryer.

Store the gloves in dry conditions.

40°C



STANDARDS:

EN 659:2003+A1:2008

EN 659:2003+A1:2008



You can find more information about the products on our website.

DuPont™, Kevlar®, Nomex® are trademarks or registered trademarks of E.I. du Pont de Nemours and Company.

