

AMBER 8123

Popular and much used model of full leather gloves with PU membrane. This model have gained popularity due to its economical cost and high sensitivity.



AMBER Long



AMBER Short

PRODUCT DESCRIPTION

Colour:	■ Black
AMBER Long	8123-04
AMBER Short	8123-05

UPPER MATERIAL:

- Cowhide – specially treated, heat, water and abrasion resistant leather.

INTERLAYERS:

- Aramid non-woven fabric.
- Membrane - PU membrane.

LINING:

- 100% cotton.

CUFF:

- **Short** - Knitted cuff made of FR viscose.
- **Long** - Extended cuff made of cowhide split and with Velcro drawstring.

OTHER INFORMATIONS:

- Reflective element.
- Carabiner for hanging the gloves to the garment.
- Drawstring waistband with velcro closure.

STANDARDS:

- EN 659:2003+A1:2008



AMBER 8123

Measurement:	Results before washing:
Abrasion resistance	4
Blade cut resistance (palm part)	2 / TDM Level B
Tear resistance	3
Puncture resistance	3
Burning behaviour	4
Convection heat resistance	4
Radiant heat resistance	2
Contact heat resistance	2
Dexterity	4

SIZE ASSORTMENT:

 cm	15,2-16,5	16,5 - 19	19 - 21,6	21,6 - 24,2	24,2 - 26,7	26,7 - 29,2	29,2 - 30,4
size	6 (XS)	7 (S)	8 (M)	9 (L)	10 (XL)	11 (2XL)	12 (3XL)

CARE & MAINTENANCE:

Choose a more ecological short washing program at 40 °C.



PROCEDURE: Remove coarse dirt after each use. Before washing, fasten the Velcro fasteners and remove the snaps. Use a liquid detergent. Wash on a short programme.

TO MAKE THE GLOVE FIT BETTER: Shape the glove several times after washing and during drying. Do not dry in direct sunlight or heat sources, do not use a tumble dryer. Store the gloves in a dry environment.

RECOMMENDED USE:

Holík Washing Gel

The washing gel is natural based for leather and textile gloves with high washing efficiency. It reduces bacteria, does not pollute the environment and is fully biodegradable (Eco-Friendly).



Impregnation spray Holík

A highly effective impregnating spray for leather and textiles that protects against moisture, water, oil and dirt while maintaining the breathability of the material. Apply the impregnation in a thin layer on dry product and allow to dry for at least 12 hours.

For more about Washing & Maintenance, visit:

www.holik-international.com > [Technologies](#) > [Care&Maintenance](#)



Co-funded by
the European Union

