

MONA 6402

Textile gloves with high protection against mechanical risks, developed for use in security, police and military environments.



MONA Short Black

PRODUCT DESCRIPTION

Cuff: Short

Color:  Black

UPPER MATERIAL:

- Back: Elastic knit PA/Spandex.
- Palm: Synthetic leather Microfibre PU/PA.

REINFORCEMENT:

- PU knuckle protector.
- Special palm filling for easier handling of weapons.
- Synthetic leather reinforcement in area between thumb and index finger prolonging lifespan of the gloves.

LINING:

- Special UHMWPE / PES / Fiberglass cut resistant lining in the whole palm including fingers.

ADDITIONAL INFORMATION:


- Special fingertip design – stitching of fingers is placed in a way to not intrude tactility and comfort of the gloves.
- Touch-screen control elements on the index finger and thumb on both left and right gloves.
- Elastic cuff with velcro fastening.
- Breathable material on back of the gloves.
- The gloves are machine washable.

SIZE ASSORTMENT:

- 6 - 7 - 8 - 9 - 10 - 11 - 12

MONA 6402

SIZE CHART:

 cm	16,5 - 19	19 - 21,6	21,6 - 24,2	24,2 - 26,7	26,7 - 29,2	29,2 - 30,4
size	7 (S)	8 (M)	9 (L)	10 (XL)	11 (2XL)	12 (3XL)

CARE & MAINTENANCE

Choose a more ecological short washing program at 40 °C.



PROCEDURE: Remove coarse dirt after each use. Before washing, fasten the Velcro fasteners and remove the snaps. Use a liquid detergent. Wash on a short programme.

TO MAKE THE GLOVE FIT BETTER: Shape the glove several times after washing and during drying. Do not dry in direct sunlight or heat sources, do not use a tumble dryer. Store the gloves in a dry environment.

RECOMMENDED USE:

Holík Washing Gel

The washing gel is natural based for leather and textile gloves with high washing efficiency. It reduces bacteria, does not pollute the environment and is fully biodegradable (Eco-Friendly).



Impregnation spray Holík

A highly effective impregnating spray for leather and textiles that protects against moisture, water, oil and dirt while maintaining the breathability of the material. Apply the impregnation in a thin layer on dry product and allow to dry for at least 12 hours.

For more about Care & Maintenance, visit:
www.holik-international.com > Technologies > Care & Maintenance



Co-funded by
the European Union

